



ARMARIOS DE LA SERIE OK

PPK 100- PLACA DE FIJACIÓN

Fixing of the upper brackets for the OK mounting plate:

The two brackets (left and right) (4) are fixed on the upper horizontal elements of the frame, (6).

They are fixed to the frame elements by two screws (9) M6x16 and the relevant cage nuts fixed to the frame elements. One cage nut is inserted into the slotted side of the bracket (8) and a screw M8x15 (7) is tightened on it.

Installation of the lower fixing elements of the PNA mounting plate:

The conic pins (2) are installed on the supporting rail (5) by nuts (1) and a M8 washer.

Two high-resistant PVC sliders are mounted on the lower part of the mounting plate, they allow the plate to slide and fit on the pins, the operation is completed by fixing the upper part.

Coupling of the mounting plates:

- mount the 4 pins (see pictures above: 2) and fix them with nuts (1) in the necessary position on the lower horizontal rail (5).
- fix the 4 brackets (4) to the upper horizontal elements of the frame (6).
- install the 4 sliders (3) in the necessary openings of the mounting plates to be coupled.
- the mounting plates must be placed on the supporting rails and must slide backwards till they reach the pins, on which they have to be installed (5).
- lean the mounting plates on the upper brackets and fix it by screws (7).
- fix the coupled mounting plates together by the necessary slots on their sides, by screws and bolts.

